

LINATRON K
MODULAR HIGH-ENERGY X-RAY SOURCE
FOR SECURITY & INDUSTRIAL SOLUTIONS



When it comes to testing for material integrity, place your trust in a company renowned for leading-edge technology with a track record spanning over 50 years. Varex Imaging's Linatron® K-Series gives users the power to inspect everything from automotive parts and castings to rockets and aerospace products. Look to Varex Imaging for the new generation of high-energy linear accelerators—and experience quality without compromise.

www.vareximaging.com

Linatron K Specifications

Performance

X-ray Beam Energy

- The nominal peak beam energies are 9 MeV and 15 MeV. Energies up to 20 MeV can be achieved.

X-ray Beam Dose Rate

- The dose rate is specified at one meter from the target, on the central axis, for one minute (Gy/min-m):
 - 9 MeV - 12 - 40 Gy/min-m
 - 15 MeV - 40 - 120 Gy/min-m
 - At 20 MeV, max output is ~ 30 Gy/min-m

X-ray Field Size

- Beam and field size are based on the collimator specified by the customer.

X-ray Beam Flatness

- Dose rate flatness as a percentage of the central axis measured at $\pm 6^\circ$ off the central axis.
 - 9 MeV - 55%
 - 15 MeV - 45%

X-ray Beam Symmetry

- The beam asymmetry does not exceed 5% at $\pm 6^\circ$ off the central axis in the vertical direction.

X-ray Beam Stability

- Dose variation is within $\pm 10\%$ after the first 10 seconds of beam on time. Use of reference detector recommended.

X-ray Beam Focal Spot Size

- The focal spot size does not exceed 2.0 mm in diameter for all energies. Consult factory for smaller spot size requirements.

Equipment Features

General Arrangement

- Horizontal Operation

Leakage Radiation

- Average leakage radiation over 100 cm² at 1 meter from the target outside of the primary beam will not exceed 0.1% of the central axis dose rate.
- The K15 high-energy photons produce significant neutron radiation. This neutron production must be considered in plant building design. Special K15 shielding limits the neutron leakage to approximately 0.1% rem/X-ray rad in the forward cone from $\pm 60^\circ$ to $\pm 90^\circ$, and 0.01 rem/X-ray rad in all other directions outside the primary beam.

Cabinet Enclosures

- All system components including the X-ray head, modulator cabinet, and the temperature control unit are contained within grounded metal enclosures.

Power

Source Description

- Linatron Power: 45 KVA at 50 or 60 Hz 400 VAC 3-phase, 3 wire plus neutral plus ground (5 wire system), 65 Amp, with 5% voltage regulation.
 - TCU Power: 26 KVA at 50 or 60 Hz
 - 400 VAC 3-phase @ 50 Hz or
 - 460 VAC 3-phase @ 60 Hz



VAREX
IMAGING

Cooling & Ventilation

Indoor Service

The room temperature for all equipment (except TCU) must be between 5°C (41°F) and 35°C (95°F) with maximum RH of 90% (non-condensing).

The standard Temperature Control Unit may operate inside or outside at temperatures from -10° to +40°C. A low temperature option allows operation to -40°C.

More Information

As the world's largest independent supplier of medical X-ray components, we have extensive experience providing high-quality, safe, and effective products.

For more information, please contact a Varex Imaging sales representative at replacement.ndt.cs@vareximaging.com or call 843-767-3005.

Varex Imaging Corporation

Headquarters

1678 Pioneer Rd.
Salt Lake City, UT 84104
Tel: 801-972-5000
Fax: 801-973-5050

Security & Industrial Products, Nevada

Las Vegas, NV
Tel: 702-938-4859
Fax: 702-938-4833

Security & Industrial Products, Illinois

Lincolnshire, IL
Tel: 847-279-5100
Fax: 847-279-4900

©2017 Varex Imaging Corporation.

All Rights reserved.

Production of any of the material contained herein in any format or media without the express written permission of Varex Imaging Corporation is prohibited.

Revision: 4 11/2017

Specifications subject to change without notice.